

<b>SUBJECT</b>	<b>PAGE NO.</b>
5.1 Specifications .....	5-1
5.2 EFI System .....	5-3
5.3 EFI Diagnostic Introduction .....	5-5
5.4 Checking For Diagnostic Trouble Codes: EFI .....	5-6
5.5 Initial Diagnostic Check: EFI .....	5-8
5.6 Speedometer Self Diagnostics .....	5-17
5.7 Breakout Box .....	5-19
5.8 Wiggle Test .....	5-20
5.9 Intake Leak Test .....	5-21
5.10 Engine Cranks, But Will Not Start .....	5-23
5.11 No ECM Power .....	5-30
5.12 Starts, Then Stalls .....	5-35
5.13 Fuel System Electrical Test .....	5-40
5.14 System Relay Check .....	5-45
5.15 Fuel Pressure Test .....	5-50
5.16 Idle Air Control, DTC P0505 .....	5-54
5.17 Misfire at Idle or Under Load .....	5-59
5.18 Combustion Absent/Intermittent, DTC P1353, P1356, P1357, P1358 .....	5-64
5.19 DTC P0107, P0108 .....	5-69
5.20 DTC P0112, P0113 .....	5-73
5.21 DTC P0117, P0118 .....	5-77
5.22 DTC P0122, P0123 .....	5-81
5.23 DTC P0261, P0262, P0263, P0264 .....	5-85
5.24 DTC P0373, P0374 .....	5-91
5.25 DTC P0501, P0502 .....	5-94
5.26 DTC P0562, P0563 .....	5-98
5.27 DTC P0603, P0605 .....	5-103
5.28 DTC P1009, P1010 .....	5-104
5.29 DTC P1351, P1352, P1354, P1355 .....	5-108
5.30 DTC U1064, U1255 .....	5-113
5.31 DTC U1097, U1255 .....	5-117

