

Table Of Contents

SUBJECT	PAGE NO.
8.1 Specifications	8-1
8.2 Bulb Chart	8-3
8.3 System Fuses	8-5
8.4 ICM (Carbureted)	8-7
8.5 Sensors (Carbureted)	8-8
8.6 Ignition Coil	8-9
8.7 Spark Plugs/Spark Plug Cables	8-10
8.8 Alternator/Stator	8-12
8.9 Voltage Regulator	8-15
8.10 Battery	8-17
8.11 Headlamp (FLHR/C/S, FLHX, FLHT/C/U)	8-23
8.12 Headlamp (FLTR)	8-26
8.13 Auxiliary Lamps	8-29
8.14 Tail Lamp Assembly	8-34
8.15 Fender Tip Lamps	8-38
8.16 Turn Signal Lamps	8-43
8.17 License Plate Lamps/Bracket (FLHX)	8-52
8.18 TSM/TSSM	8-54
8.19 Ignition/Light Key Switch And Fork Lock	8-55
8.20 Fairing Cap Switches (FLHTC/U)	8-60
8.21 Instrument Nacelle Switches (FLTR)	8-62
8.22 Handlebar Switches	8-66
8.23 Stoplight Switches	8-83
8.24 Neutral Switch	8-84
8.25 Oil Pressure Switch/Sender	8-85
8.26 Horn	8-86
8.27 Cigarette Lighter (FLHX, FLHT/C/U, FLTR)	8-87
8.28 Gauges/Instruments (FLHX, FLHT/C/U, FLTR)	8-88
8.29 Gauges/Instruments (FLHR/C/S)	8-92
8.30 Fuel Level Sender (Carbureted)	8-96
8.31 Cruise Control (FLHRC, FLHTCU, FLTR)	8-101
8.32 Advanced Audio System (FLHX, FLHTC/U, FLTR)	8-109
8.33 Wire Trough	8-116
8.34 Main Harness	8-119
8.35 Interconnect Harness	8-133
8.36 Radio Antenna Cable	8-141
8.37 Audio Harness (FLHTCU)	8-145
8.38 CB Antenna Cable (FLHTCU)	8-149

ELECTRICAL

NOTE

*See the 2006 ELECTRICAL DIAGNOSTIC MANUAL
(Part No. 99497-06) for all SYSTEM DIAGNOSIS and
ELECTRICAL TROUBLESHOOTING information.*

