

SUBJECT	PAGE NO.
3.1 Specifications	3-1
Manufacturing Tolerances	3-1
3.2 Service Wear Limits	3-3
3.3 General Information	3-5
3.4 How To Use This Section	3-14
3.5 Stripping Motorcycle For Service	3-16
3.6 Assembling Motorcycle After Stripping	3-17
3.7 Removing Engine From Chassis	3-19
3.8 Installing Engine In Chassis	3-23
3.9 Top End Overhaul	3-29
Disassembly	3-29
Assembly	3-33
3.10 Bottom End Overhaul	3-41
Disassembly	3-41
Assembly	3-43
3.11 Subassembly Service And Repair	3-51
Breather Assembly	3-51
Rocker Arm Assembly	3-52
Push Rods/Lifters/Covers	3-55
Cylinder Head	3-59
Cylinder	3-68
Piston	3-71
Upper Connecting Rod	3-76
Cam Support Plate	3-81
Oil Pump	3-93
Crankcase	3-95
Flywheel/Connecting Rod Assembly	3-102