

<b>SUBJECT</b>	<b>PAGE NO.</b>
4.1 Specifications .....	4-1
4.2 Diagnostic Introduction .....	4-2
4.3 Checking For Trouble Codes .....	4-3
4.4 Initial Diagnostic Check: ICM .....	4-5
4.5 Speedometer Self Diagnostics .....	4-12
4.6 Breakout Box .....	4-14
4.7 Wiggle Test .....	4-15
4.8 Intake Leak Test .....	4-16
4.9 Engine Cranks, But Will Not Start .....	4-18
4.10 Starts and Then Stalls .....	4-23
4.11 No Spark/No ICM Power .....	4-28
4.12 Misfire .....	4-30
4.13 DTC P0106, P0107, P0108 .....	4-33
4.14 DTC P0562, P0563 .....	4-37
4.15 DTC P1009, P1010 .....	4-41
4.16 DTC P1351, P1352, P1354, P1355 .....	4-45
4.17 DTC P0371, P0372, P0374 .....	4-49
4.18 DTC P0501, P0502 .....	4-52
4.19 DTC P0602, P0603, P0604, P0605, P0607 .....	4-56
4.20 DTC U1064 .....	4-57
4.21 DTC U1097 .....	4-61

