

Table Of Contents

<b>SUBJECT</b>	<b>PAGE NO.</b>
3.1 TSM/TSSM Overview .....	3-1
3.2 TSM/TSSM Features .....	3-3
3.3 TSM/TSSM Vehicle Delivery .....	3-5
3.4 TSM/TSSM Turn Signal Functions .....	3-10
3.5 TSM/TSSM Bank Angle Function .....	3-12
3.6 TSSM Security Functions .....	3-13
3.7 TSSM Arming/Disarming .....	3-17
3.8 Checking For Diagnostic Trouble Codes .....	3-19
3.9 Initial Diagnostic Check: TSM/TSSM .....	3-22
3.10 Speedometer Self Diagnostics .....	3-31
3.11 Breakout Box (TSM/TSSM) .....	3-33
3.12 No Security Lamp at Key ON .....	3-34
3.13 Security Lamp on Continuously .....	3-39
3.14 Key Fob Signal To TSSM Weak or Fails .....	3-43
3.15 Turn Signal Errors .....	3-46
3.16 DTC B0563 .....	3-57
3.17 DTC B1131, B1132 .....	3-58
3.18 DTC B1134 .....	3-61
3.19 DTC B1135 .....	3-64
3.20 DTC B1151, B1152, B1153 .....	3-65
3.21 DTC U1016 .....	3-68
3.22 DTC U1097, U1255 .....	3-74
3.23 DTC U1300, U1301 or "BUS Er" .....	3-80
3.24 Password Learn .....	3-81
3.25 TSSM Maintenance .....	3-83

