

SUBJECT	PAGE NO.
5.1 Specifications	5-1
5.2 Starter System	5-2
5.3 Starter Relay	5-4
5.4 Starter	5-6
5.5 Starter Solenoid	5-13
5.6 Starter Jackshaft	5-14

NOTE

*See the 2006 ELECTRICAL DIAGNOSTIC MANUAL
(Part No. 99497-06) for all SYSTEM DIAGNOSIS and
ELECTRICAL TROUBLESHOOTING information.*

